





Assembly Instruction



Fila
model 88** NA A00 H4





Assembly Instruction



|Fila


model 883P NA A00 HL
884P NA A00 HL
885P NA A00 HL
883C NA A00 HL
884C NA A00 HL
885C NA A00 HL






FILA 2

models: 887*NA A00T HL
888*NA A00T HL

1




2




**ASSEMBLY
INSTRUCTIONS**




1




2



**USER
INSTRUCTIONS**



Assembly Instruction



FILA 3

model : 1333*NAA00HL
1334*NAA00HL

